

Cleaning (regular)

- Frames The frames are powder coated and only require a general all-purpose cleaner such as Formula 409
- Polycarbonate Panels (all clear safety panels, Krystal, and 3D Models) see manufacturers specific cleaning instructions below
- Climbing Holds CLR, Barkeepers friend and Zud. Also Mr. Clean Magic Eraser works well
- Both frames and panels can be power-washed using ONLY non-chlorinated water

Polycarbonate Cleaning Instructions

The following techniques for cleaning polycarbonate sheet are based on standard industry practice. To ensure acceptability of the results, always test a sample of the material with the cleaner and technique to be used.

Guidelines:

Do rinse the sheet with warm water prior to cleaning process.

Don't use abrasives or high alkaline cleaners.

Don't leave cleaners on sheet for long periods, wash immediately.

Don't apply cleaners in direct sunlight or at elevated temperatures

Don't use scrapers, squeegees or razors.

Don't clean with gasoline.

Do follow the application with a lukewarm water rinse.

Compatible Cleaners and Detergents:

Formula 4091, Joy2, Windex with Ammonia D3, Palmolive4, Naphtha VM&P Grade, Isopropyl Alcohol

To Minimize Fine or Hairline Scratches:

Plastic Polishes applied and removed per manufacturer instructions.

Suggested Polishes:

Mirror Glaze Clear Plastic Polish, Cleaner & Detailer (by Meguiars 800-347-5700 or Meguiars.com)

Novus Plastics Polish #1, #2 (by Novus Inc. 800-NOVUS60 or noscratch.com)

Plexus Plastic Cleaner and Polish (by BTI Chemical Co. PlexusPlasticCleaner.com)

To Remove Masking Adhesive and Glazing Compound:

Apply Naphtha VM&P grade, Kerosene or Isopropyl Alcohol with clean soft cloth. Wash immediately with soap and lukewarm water and rinse with thoroughly with clean water.

To Remove Graffiti:

Naphtha VM&P grade, Isopropyl Alcohol or Butyl Cellosolve removes paint, marker ink. (Do not use in direct sunlight).

Isopropyl Alcohol, Naphtha VM&P grade or Kerosene will help lift stickers and other adhesive

backed labels. Wash immediately with soap and lukewarm water and rinse with thoroughly with clean water.


Routine maintenance (monthly)

- Frames
- A Check the FOUR nuts and/or bolts on each base for the correct torque (90 ft-lbs)
- B- Check the Clevis and Cotter Pin to ensure correctly installed
- Check the bolts and Nuts on both the Diagonal Braces and Stabilizer Bars for tightness
- Check the Frame Connector bolts for tightness

and/or

panels

climbing




Refer to Assembly Guide for number and

location of components to be serviced.

Changing the experience

(Every three months if desired)

- Panels (Only for 3D models)
 - Rotate and relocate the panels
- Climbing Holds
- Rotate, relocate, add or subtract holds using using pre-drilled holes



Safety signage

• Safety Signage for AquaClimb products must be visible to the climbers at all times.